

BASIC INSTRUCTIONS RR ACRO BRAKES

TO ATTACK THE BRAKE LINE

1. Pull down the neoprene and open de red strap
- 2 - 3. Pass the brake line throught the red strap
4. Tired the brake line
5. The black mark must be in the middle
- 6 - 7. Make the knot as pictures
8. Press the knot
9. Pull up the neoprene

TO ADJUST THE LENTH OF BRAKE LINE

10. You can change the black mark from the brake line to make sorther or longer your brakes
11. Put both brakes together with both marks at the same distance, and make the knot again as (6 - 7 - 8 - 9)

TO PUT THE ELASTIC LINE

12. With RR ACRO WINGS serial risers
13. With other risers
14. Put the elastic line in the attachment
15. Choice your length in the elastic line
16. Put the rest of the elastic line in the pocket

